


Urn-style Rain Barrel with Planter

Your environmentally friendly water saver.

Congratulations on the purchase of your urn style rain barrel with planter. Making use of free rainwater for your lawn and garden is a smart choice. It not only saves money but is less of a drain on municipal water or well-water sources. Plus rainwater is healthier for plants.



Warning - Winter Storage


If you live in a cold climate, drain the barrel and hoses completely. Hoses should be stored inside. Place the barrel upside down to avoid water freezing and cracking the barrel.

Assembly and installation of Urn-style rain barrel

1. Take the garden hose that comes with your barrel. It has a convenient thumb valve at one end. Attach the other end of this hose to the threaded fitting at the front base of the barrel. Once it is secured, lift the valve end up to the top of the barrel and place it in the hose clip on the top of the barrel. This will keep the outlet hose off the ground and easily accessible.


2. Next place the debris screen on the top of the barrel.

This strong plastic mesh screen will keep out leaves, shingle grit, other debris as well as safely protecting animals and pets from entering the barrel. As needed, you may remove the debris screen and rinse it off



3. Please note that the barrel must be placed on as flat a surface as possible. It is recommended that you use a leveled base like a patio stone to prevent shifting or tipping. Make sure the grade around your house allows excess water to fall away from house.

4. Before positioning your barrel, you will need to shorten your current downspout so that the water will exit into the barrel. Begin by measuring how much you will need to cut out of the downspout so that the elbow fits completely into the mouth of the barrel funnel. First remove the curved elbow end portion of the existing downspout. Trim the straight portion of the downspout to the desired new length. Once you reattach the elbow to the shortened vertical downspout you are ready to place the barrel underneath it for easy cleaning.




Drawing Water from the Barrel:

To draw water use the outlet hose attachment. It is useful for filling watering cans or buckets and can easily connect to a longer piece of garden hose which will direct water to other sections of your lawn or gardens. The hose can also be used to drain the barrel by removing the thumb valve.

Winter Storage:

If you live in a cold climate, drain the barrel and hoses completely. Hoses should be stored inside. Place the barrel upside down to avoid water freezing and cracking the barrel.


The rain barrel will hold up to 54 US gallons or 205 litres of rainwater. This may seem like a lot of water but when you consider that a roof area of 1,000 square feet will capture 625 gallons from just one inch of rainfall. (92.9 m² captures 2,365 litres from 1 cm of rainfall) —which means, that your rain barrel will fill quickly.



Cuve pluviale en forme d'urne avec jardinière

Votre économiseur d'eau écologique.

Félicitations d'avoir acheté la cuve pluviale en forme d'urne. C'est un choix intelligent que d'utiliser l'eau de pluie pour arroser votre pelouse et jardin. Non seulement économiserez-vous de l'argent, mais aussi vous n'épuiserez pas les eaux municipales ou les eaux de puits. De plus, l'eau de pluie est plus saine pour les plantes.




Avertissement – Entreposage hivernal

Si vous vivez dans un climat froid, vidangez la cuve et les tuyaux complètement. Rangez les tuyaux à l'intérieur. Placez la cuve sens dessus dessous pour éviter que l'eau ne gèle et ne fissure la cuve.

Montage et installation de la cuve pluviale en forme d'urne


1. Tenez en main le tuyau d'arrosage fourni avec la cuve à partir de l'extrémité de la vanne très pratique. Branchez l'autre extrémité de ce tuyau au raccord fileté à la base avant de la cuve. Une fois qu'il est sécurisé, relevez l'extrémité du tuyau dotée de la vanne et placez-la dans la pince d'accrochage sur le dessus de la cuve. De cette façon, vous ne laisserez pas le tuyau traîner par terre et le rendrez facilement accessible.

2. Ensuite, posez le tamis par-dessus la cuve. Ce tamis solide en plastique à mailles prévient l'entrée dans la cuve des feuilles, des grenailles de bardeaux et d'autres débris, et y interdit l'accès aux animaux sauvages et domestiques. Au besoin, vous pouvez enlever le tamis et le rincer pour un nettoyage facile.



3. Veuillez noter que la cuve doit être posée sur une surface aussi plane que possible. Il est recommandé que vous utilisiez une base nivelée, comme une dalle de patio en vue d'empêcher que la cuve ne se déplace ni ne tombe. Assurez-vous que le niveau du sol autour de votre maison permet que le surplus d'eau coule loin de la maison.

4. Avant de positionner votre cuve, vous devrez raccourcir votre tuyau de descente actuel de façon que l'eau aboutisse dans la cuve. Commencez par mesurer la longueur de tuyau à découper pour que le coude s'insère complètement dans la bouche de la cuve. Commencez par retirer le coude du tuyau de descente. Coupez la partie verticale du tuyau à la nouvelle longueur désirée. Une fois que vous avez rattaché le coude au tuyau vertical raccourci, vous pouvez positionner la cuve en dessous.



Utilisation de l'eau de la cuve :

Pour extraire l'eau, utilisez le tuyau de sortie pour remplir des arrosoirs ou des seaux, ou le connecter à un tuyau d'arrosage plus long, qui servira à diriger l'eau vers d'autres parties de votre pelouse ou jardin. Vous pouvez également vous servir du tuyau pour vidanger la cuve en retirant la vanne.

Entreposage hivernal :

Si vous vivez dans un climat froid, vidangez la cuve et les tuyaux complètement. Rangez les tuyaux à l'intérieur. Placez la cuve sens dessus dessous pour éviter que l'eau ne gèle et ne fissure la cuve.

La cuve pluviale peut contenir jusqu'à 54 gallons américains (205 litres) de pluie. Cela peut sembler beaucoup d'eau, mais quand vous considérez qu'une surface de toiture de 1000 pieds carrés permet de saisir 625 gallons d'un seul pouce de pluie (92,9 m saisis 2 365 litres d'un cm de pluie), la cuve se remplira rapidement.

